


## KONFIGURACJA JEDNOSTEK WEWNĘTRZNYCH W SYSTEMIE „MULTI”

A2M-50HMVO	1 jednostka		2 jednostki					
	7		7+7	9+9				
	9		7+9	9+12				
	12		7+12	12+12				
	18		7+18					
A3M-60HMVO	1 jednostka	2 jednostki		3 jednostki				
	7	7+7	9+9	7+7+7	7+9+9			
	9	7+9	9+12	7+7+9	7+9+12			
	12	7+12	9+18	7+7+12				
	18	7+18	12+12	9+9+9				
A4M-80HMVO	1 jednostka	2 jednostki			3 jednostki			
	7	7+7	9+9	12+18	7+7+7	7+9+9	7+12+18	9+12+12
	9	7+9	9+12	18+18	7+7+9	7+9+12	9+9+9	9+12+18
	12	7+12	9+18		7+7+12	7+9+18	9+9+12	12+12+12
	18	7+18	12+12		7+7+18	7+12+12	9+9+18	
				4 jednostki				
				7+7+7+7	7+7+9+9	7+9+9+12		
				7+7+7+9	7+7+9+12	7+9+12+12		
				7+7+7+12	7+7+12+12	9+9+9+9		
				7+7+7+18	7+9+9+9	9+9+9+12		

### JEDNOSTKI WEWNĘTRZNE :

ASHM-21HMVI ..... ścienna „ 7 ” kBTU  
 ASHM-25HMVI ..... ścienna „ 9 ” kBTU  
 ASHM-35HMVI ..... ścienna „ 12 ” kBTU  
 ASHM-50HMVI ..... ścienna „ 18 ” kBTU

ASFM-35HMVI ..... przypodłogowo-sufitowa „ 12 ” kBTU  
 ASFM-50HMVI ..... przypodłogowo-sufitowa „ 18 ” kBTU

ASKM-35HMVI ..... kasetonowa „ 12 ” kBTU  
 ASKM-50HMVI ..... kasetonowa „ 18 ” kBTU